



Direct Supply®

1.7 CU. FT. OVER THE RANGE MICROWAVE

Owner's Manual

Please keep and refer to this Owner's Manual.

Thank you for purchasing a Direct Supply® 1.7 Cu. Ft. Over the Range Microwave. Please read this entire guide carefully and keep it for future reference. This guide will provide you with instructions, warnings, warranty information, and other important information about your microwave. Share this information with those individuals who will be assembling, using, servicing, and/or cleaning the product to help ensure it is cared for properly.

Table of Contents

Precautions to Avoid Possible	
Exposure to Excessive Microwave Energy	3
Important Safety Instructions	4 - 5
Grounding Instructions	6
Radio Interference	7
Utensils.....	8 - 9
Names of Oven Parts and Accessories	10
Operation.....	11 - 16
Maintenance.....	17
Limited Warranty	18
Customer Service.....	19

Precautions to Avoid Possible Exposure to Excessive Microwave Energy

- (a) Do not attempt to operate this oven with the door open since open door operation can result in harmful exposure to microwave energy.
It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allows soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - (1) DOOR (bent)
 - (2) HINGES AND LATCHES (broken or loosened)
 - (3) DOOR SEALS AND SEALING SURFACES
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

Specifications

Model	0-3F6GH
Rated Voltage/Frequency	120V AC 60Hz
Microwave Input	1550 W
Microwave Output	1000 W
Oven Capacity:	1.7ft ³ / 48L
Turntable Diameter:	12.4" / 31.5cm
External Dimensions:	29.9"x15.4"x16.4" / 76x39.2x41.7cm
Net Weight:	Approx. 49lbs / 22.2kgs

Important Safety Instructions

When using electrical appliances basic safety precautions should be followed, including the following:

⚠ WARNING - To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

1. Read all instructions before using the appliance.
2. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY "
3. This appliance must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS"
4. Install or locate this appliance only in accordance with the provided installation instructions.
5. Some products such as whole eggs and sealed containers - for example, closed glass jars - are able to explode and should not be heated in this oven.
6. Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.
7. HOT CONTENTS CAN CAUSE SEVERE BURNS. DO NOT ALLOW CHILDREN TO USE THE MICROWAVE. Use caution when removing hot items.
8. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
9. This appliance should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair, or adjustment.
10. Do not cover or block any openings on the appliance.
11. Do not store this appliance outdoors. Do not use this product near water - for example, near a kitchen sink, in a wet basement, near a swimming pool, or similar location.
12. Do not immerse cord or plug in water.
13. Keep cord away from heated surface.
14. Do not let cord hang over edge of table or counter.
15. When cleaning surfaces of door and oven that comes together on closing the door, use only mild, nonabrasive soaps, or detergent applied with a sponge or soft cloth.
16. To reduce the risk of fire in the oven cavity:
 - 1). Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - 2). Remove wire twist-ties from paper or plastic bag before placing bag in oven.
 - 3). If material inside of the oven ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - 4). Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.

17. Liquids, such as water, coffee, or tea are able to be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from the microwave oven is not always present.

THIS COULD RESULT IN VERY HOT LIQUID SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.

To reduce the risk of injury to persons:

- 1) Do not overheat the liquid.
 - 2) Stir the liquid both before and halfway through heating it.
 - 3) Do not use straight-sided containers with narrow necks.
 - 4) After heating, allow the container to stand in the microwave oven for a short time before removing the container.
 - 5) Use extreme care when inserting a spoon or other utensil into the container.
18. Do not operate any heating or cooking appliance beneath the appliance.
(Exception: A microwave oven investigated for use above another heating appliance.)
19. Do not mount unit over or near any portion of heating or cooking appliance.
(Exception: A microwave oven investigated for use above another heating appliance.)
20. Do not mount over sink.
21. Do not store anything directly on top of the appliance surface when the appliance is in operation.
22. Clean Ventilation Hoods Frequently - Grease should not be allowed to accumulate on hood or filter.
23. When flaming foods under the hood, turn the fan on.
24. Use care when cleaning the vent-hood filter. Corrosive cleaning agents, such as lye-based oven cleaners, may damage the filter
25. Suitable for use above both gas and electric cooking equipment.

**SAVE THESE INSTRUCTIONS HOUSEHOLD USE ONLY
(NOT FOR COMMERCIAL USE)**

Grounding Instructions

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

⚠ WARNING - Improper use of the grounding can result in a risk of electric shock. Consult a qualified electrician or serviceman if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounded plug, and 3-slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord shall be equal to or greater than the electrical rating of the appliance.

⚠ DANGER - Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

⚠ WARNING - Electric Shock Hazard

Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

1. A short power supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer cord sets or extension cords are available and may be used if care is exercised in their use.
3. If a long cord or extension cord is used:
 - 1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
 - 2) The extension cord must be a grounding-type 3-wire cord.
 - 3) The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

Radio Interference

1. Operation of the microwave oven may cause interference to your radio, TV or similar equipment.
2. When there is interference, it may be reduced or eliminated by taking the following measures:
 - 1) Clean door and sealing surface of the oven
 - 2) Reorient the receiving antenna of radio or television.
 - 3) Relocate the microwave oven with respect to the receiver.
 - 4) Move the microwave oven away from the receiver.
 - 5) Plug the microwave oven into a different outlet so that microwave oven and receiver are on different branch circuits.
3. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - 1) Reorient or relocate the receiving antenna.
 - 2) Increase the separation between the equipment and receiver.
 - 3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - 4) Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 18 of the FCC Rules.

Utensils

⚠ CAUTION - Personal Injury Hazard

Tightly-closed utensils could explode. Closed containers should be opened and plastic pouches should be pierced before cooking.

See the instructions on “Materials you can use in microwave oven or to be avoided in microwave oven.”

There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250 ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.


Materials you can use in microwave oven

Utensils	Remarks
Browning dish	Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch (5 mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer's instructions. Should be labeled “Microwave Safe”. Some plastic containers soften, as the food inside gets hot. “Boiling bags” and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

Materials to be avoided in microwave oven


Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

Names of Oven Parts and Accessories




- 1** Microwave oven door with see-through window
- 2** Door hinges
- 3** Waveguide cover:
DO NOT REMOVE.
- 4** Turntable motor shaft
- 5** Microwave oven light
It will light when microwave oven is operating or door is open.

- 6** Rack holders
- 7** Safety door latches
The microwave oven will not operate unless the door is securely closed.
- 8** Handle
- 9** Control Panel
- 10** Display screen
- 11** Ventilation openings
- 12** Rating label



Glass turntable



Turntable Ring Assembly

Operation

- Before operating your new oven make sure you read and understand this Use and Care Guide completely.
- The clock can be disabled when the microwave is first plugged in and the STOP key is selected. To re-enable the clock follow clock instructions.

Setting the Clock

Suppose you want to enter the correct time of day 10:59

Touch	Display Shows:
1. Clock	12:00 (Current time)
2. ① ⑩ ⑤ ⑨	10:59 <small>PRESS START</small>
3. Clock or Start+30sec.	10:59

Setting the Timer

Your microwave oven can be used as a kitchen timer. You can set up to 99 minutes, 99 seconds. The kitchen timer can be used while the microwave oven is running.

- Suppose you want to set for three minutes.

Touch	Display Shows:
1. Timer	<small>TIMER</small> : 0
2. ③ ⑩ ⑩	<small>TIMER</small> 3:00
3. Timer	<small>TIMER</small> 3:00 (Time counting down)

NOTE: There are not any other programs during the kitchen timer

Microwave

Your Over the Range Microwave Oven can be programmed for 99 minutes 99 seconds (99:99). Always enter the seconds after the minutes, even if they are both zeros.

- Suppose you want to cook for 2 minutes at 90% power

Touch	Display Shows:
1. Cook Time	: 0
2. ② ⑩ ⑩	2:00 <small>PRESS START</small>
3. Power Level x1	P-HI <small>PRESS START</small>
4. Power Level x1 or ⑨	P-90 <small>PRESS START</small>
5. Start+30sec.	<small>COOK</small> 2:00

Power Chart

Press	Power Level	Display
Power Level X 1	100%	P-Hi
Power Level X 2 or 9	90%	P-90
Power Level X 3 or 8	80%	P-80
Power Level X 4 or 7	70%	P-70
Power Level X 5 or 6	60%	P-60
Power Level X 6 or 5	50%	P-50
Power Level X 7 or 4	40%	P-40
Power Level X 8 or 3	30%	P-30
Power Level X 9 or 2	20%	P-20
Power Level X 10 or 1	10%	P-10
Power Level X 11 or 0	0%	P-0

Operation (cont.)

Weight Defrost

Touch	Display Shows:
1. DefrostX1	SEE MENU LABEL 0.0
2. ① ②	PRESS START 1.2 lb
3. Start+30sec.	Time counting down

Time Defrost

Touch	Display Shows:
1. DefrostX2	SEE MENU LABEL 0:00
2. ① ② ③ ④	PRESS START 12:00
3. Start+30sec.	COOK DEFR 12:00 (Time counting down)

NOTE: The buzzer will sound to remind you of turning over the food when half of the time has passed on.

Speed Cooking

Using Add 30 Sec.

This is a time-saving pad. It is a simplified feature that lets you quickly set and start microwave cooking at 100% power.

Touch	Display Shows:
1. Start+30sec.	COOK :30

Using Number Pads For "1-6"

Press number pads "1-6" to start cooking with corresponding time for 100% power level directly.

For example, cooking with 3 minutes for 100% power level.

Touch	Display Shows:
1. ③	PRESS START : 3
2. After 2 seconds	COOK 3:00

The oven should be opened and closed in 5 minutes before the speed cooking, otherwise, operating as below.

Touch	Display Shows:
1. ②	Food
2. Open the door	PRESS START 2:00
3. Start+30sec.	Time counting down (Close the door)

NOTE: "Food" will be displayed if a quick start cooking cycle or +30 sec key is not selected within 5 minutes of placing food in the microwave. You must open then close the door again to clear "Food" from the display.

Veggies

Touch	Display Shows:
1. VeggiesX1	SEE MENU LABEL Fr-1
VeggiesX2	SEE MENU LABEL Fr-2
2. ①	PRESS START 1CUP
3. Start+30sec.	Time counting down

Popcorn

Press "Popcorn" key and LED displays 3.3 oz.
Press "Popcorn" repeatedly to choose the desired weight.

- Suppose you want to cook 3.0 oz. popcorn.

Touch	Display Shows:
1. Popcorn	SEE MENU LABEL. PRESS START 3.3 oz
2. PopcornX1	SEE MENU LABEL. PRESS START 3.0 oz
3. Start+30sec.	Time counting down
Press popcorn pad	Amount
X1	3.3 oz
X2	3.0 oz
X3	1.75 oz

Potato

Touch	Display Shows:
1. Potato	SEE MENU LABEL. PRESS START 1
2. PotatoX1 or ②	SEE MENU LABEL. PRESS START 2
3. Start+30sec.	Time counting down
Press potato pad or number keys	Amount
X1	1
X2	2
X3	3
X4	4

Snack Menus

There are 4 options (Hot dogs,Frozen Kids Meal Meal In A Cup,Soup)under the snack menu.

- (Hot dogs,Soup)

Touch	Display Shows:	
1. Snack MenusX1	SEE MENU LABEL 5n-1	
2. ①	PRESS START 1	
3. Start+30sec.	Time counting down	
Press snack menu pad	Food	Amount
X1	Hot Dogs	1-6 pieces
X2	Frozen Kids Meal	8.8 oz
X3	Meal in a cup	2.39 oz
X4	Soup	1-2 cups

- (Frozen Kids Meal,Meal In A Cup)

Touch	Display Shows:
1. Snack MenusX2	SEE MENU LABEL 5n-2
2. Start+30sec.	Time counting down

Operation (cont.)

Auto Cook

There are 5 options (Bacon, Dinner Plate, Rice, Frozen breakfast, Frozen Pizza) under the auto cook.

Touch	Display Shows:	
1. Auto cookX1	<small>SEE MENU LABEL</small> AC-1	
2. ②	<small>PRESS START</small> 2	
3. Start+30sec.	Time counting down	
Press auto cook	Food	Amount
X1	Bacon	1-3 Slices
X2	Dinner Plate	1-2 Plates
X3	Rice	1-2 Cups
X4	Frozen breakfast	8/12 oz
X5	Frozen Pizza	6/8/12 oz

Melt/Soften

The oven uses low power to melt and soften items.

See the following table.

- Suppose you want to melt 2 sticks of Butter.

Touch	Display Shows:	
1. Melt/Soften X1	SEE MENU LABEL 50-1	
2. ②	PRESS START 2	
3. Start+30sec.	Time counting down	
Press Melt Soften Pad	Food	Amount
X1	Melt Butter	1/2 stick
X2	Melt Chocolate	2/4/8 oz
X3	Soften Ice Cream	Pint/1.5Quart
X4	Soften Cream Cheese	3/8 oz

Safety Lock

Touch	Display Shows:
1. STOP/CLEAR (for 3 seconds)	<small>LOCK</small> or <small>LOCK</small> 11:00 (if clock is set)
2. STOP/CLEAR (for 3 seconds)	(if clock is set)

Stage Cook


At most two stages of microwave can be set. Defrost can't be one of the multi-stage.

Touch	Display Shows:
1. ① ② ③	<small>PRESS START</small> 1:20
2. Power Level	<small>PRESS START</small> P-H1
3. Power Level X8 or ②	<small>PRESS START</small> P-20
4. Cook Time	: 0
5. ① ③ ⑤ ⑨	<small>PRESS START</small> 10:59
6. Power Level	<small>PRESS START</small> P-H1
7. Power Level X7 or ③	<small>PRESS START</small> P-30
8. Start+30sec.	Time counting down

Vent Fan

The pad controls the 2-speed vent fan. If the vent fan is OFF, the first touch of the Vent pad will turn the fan on HIGH, second touch LOW and third touch OFF.



- Suppose you want to set the vent fan speed to LOW from the OFF position.

Touch	Display Shows:
1.  x1	HI
2.  x2	Lo
3.  x3	OFF

Light

The pad controls the 2-states light. If the light is OFF the first touch of the light pad will turn the light on ON , second touch OFF

- Suppose you want to set the light for ON from the OFF position.

Touch	Display Shows:
1.  x1	ON
2.  x2	OFF

User Preference

Key	Setting
USER PREFx1	Volume Hi / Med /Low/Off
USER PREFx2	Weight lb/kg
USER PREFx3	Clock Display Off/On
USER PREFx4	Demo Mode

Volume LOW/NOR/HI/OFF

In waiting state

Touch:	Display Shows:
1. USER PREFx1	SEE MENU LABEL. PRESS START oP-1
2. Start+30sec.	Lo (Lo,nor,HI,oFF will display in order))
3. Start+30sec.	Lo

Weight (LBS / KG)

In waiting state

Touch:	Display Shows:
1. USER PREFx1	SEE MENU LABEL. PRESS START oP-2
2. Start+30sec.	PRESS START oP-2 lb or oP-2 kg PRESS START
3. Start+30sec.	Time counting down

Operation *(cont.)*

Clock Display OFF/ON

In waiting state

Touch:	Display Shows:
1. USER PREFx3	<small>SEE MENU LABEL. PRESS START</small> oP-3
2. Start+30sec.	<small>PRESS START</small> oFF or <small>PRESS START</small> oN
3. Start+30sec.	Time counting down

Demo Setting

In waiting state

Touch:	Display Shows:
1. USER PREFx4	<small>SEE MENU LABEL. PRESS START</small> oP-4
2. Start+30sec.	<small>PRESS START</small> oFF or <small>PRESS START</small> oN
3. Start+30sec.	Time counting down

Maintenance

Troubleshooting

Check your problem by using the chart below and try the solutions for each problem. If the microwave oven still does not work properly, contact the nearest authorized service center.

Trouble	Possible Cause	Possible Remedy
Oven will not start	a. Electrical cord for oven is not plugged in. b. Door is open. c. Wrong operation is set.	a. Plug into the outlet. b. Close the door and try again. c. Check instructions.
Arcing or sparking	a. Materials to be avoided in microwave oven were used. b. The oven is operated when empty. c. Spilled food remains in the cavity.	a. Use microwave-safe cookware only. b. Do not operate with oven empty. c. Clean cavity with wet towel.
Unevenly cooked foods	a. Materials to be avoided in microwave oven were used. b. Food is not defrosted completely. c. Cooking time, power level is not suitable. d. Food is not turned or stirred.	a. Use microwave-safe cookware only. b. Completely defrost food. c. Use correct cooking time, power level. d. Turn or stir food.
Overcooked foods	Cooking time, power level is not suitable.	Use correct cooking time, power level.
Undercooked foods	a. Materials to be avoided in microwave oven were used. b. Food is not defrosted completely. c. Oven ventilation ports are restricted. d. Cooking time, power level is not suitable.	a. Use microwave-safe cookware only. b. Completely defrost food. c. Check to see that oven ventilation ports are not restricted. d. Use correct cooking time, power level.
Improper defrosting	a. Materials to be avoided in microwave oven were used. b. Cooking time, power level is not suitable. c. Food is not turned or stirred.	a. Use microwave-safe cookware only. b. Use correct cooking time, power level. c. Turn or stir food.

Limited Warranty

We offer to you, as the original purchaser, a warranty for the Direct Supply® 1.7 Cu. Ft. Countertop Microwave. Our warranty applies for the limited warranty period stated below. If any device or device part listed below is defective in material or workmanship during the applicable limited warranty period, we will repair or replace it at our cost. Please note that the decision to repair or replace a device or device part will be at our discretion. Our warranty applies only if the device is properly maintained by the original purchaser for normal, indoor use and does not cover normal wear and tear, modification of the device, or damage caused by abuse, improper use, failure to maintain, use which exceeds the published device limitations, or the combination of any device with another product. In addition, our warranty does not cover fading, colorfastness, stains, spills or exposure to chemicals, odors, heat or light. In certain cases, we may provide you repair or adjustment instructions and/or replacement parts and ask you to perform a repair or adjustment or replace a defective part.

Our warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. Please note that our limited warranty period begins when we ship the device to you. The limited warranty period and our obligations under the warranty end once you transfer the device to someone else or at the end of the applicable limited warranty period identified below, whichever is earlier.

Device	Warranty Period	Anticipated Usable Product Life
Direct Supply 1.7 Cu. Ft. Countertop Microwave	1 year	1 year

Anticipated Usable Product Life is based on normal use with proper maintenance, cleaning and storage. You should still inspect, monitor and care for the product as described in this guide, as the product may need to be replaced sooner than anticipated in particular situations.

DIRECT SUPPLY MANUFACTURING, INC. MAKES NO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE; THESE AND ALL OTHER IMPLIED WARRANTIES ARE SPECIFICALLY DISCLAIMED. TO THE FULLEST EXTENT ALLOWED BY LAW, DIRECT SUPPLY MANUFACTURING, INC. WILL NOT BE LIABLE FOR ANY INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, OR LOST PROFITS THAT MAY RESULT FROM THE PRODUCT OR YOUR USE OF OR INABILITY TO USE THE PRODUCT EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. OUR TOTAL LIABILITY TO YOU, IF ANY, IS LIMITED TO THE PRICE OF THE PRODUCT OR SERVICE GIVING RISE TO YOUR CLAIM. Some states do not allow an exclusion or limitation of incidental or consequential damages, or how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. If implied warranties are not excluded, and to the extent allowed by law, we limit any and all implied warranties to the applicable warranty period identified above. Except for rights under any applicable state law, the remedies provided under this warranty are your sole and exclusive remedy for any breach of our warranty and state the entire limit of our responsibilities.

Customer Service

Our promise to you is that you will have a convenient and easy ordering experience, receive a quality microwave and enjoy outrageous customer service. If you have any questions about the appliance you have purchased or would like to request warranty service, please contact the distributor from whom you purchased the appliance.



Distributed by Direct Supply® Manufacturing™, Inc. 6635 W Champions Way, Milwaukee WI 53223.

© 2024 Direct Supply Manufacturing, Inc. All Rights Reserved. Direct Supply and all associated logos are the registered trademarks of Direct Supply, Inc., used under license. All other trademarks are the property of their respective owners.