


# Direct Supply®

# PAN RACKS & TRANSPORT CABINETS

Owner's Manual and Assembly Instructions



# **Cleaning of Pan Racks or Transport Cabinets**

- Only use cleaning products specified as being aluminum or stainless steel safe, depending on the unit material. Never use chlorides, bromides or iodides to clean the unit, as this may cause corrosion. Consult the label or cleaner manufacturer for proper use.
- Rinse with fresh water immediately after every cleaning, and wipe dry to remove any water residue.
- Do not use any metal brushes, metal cleaning pads or steel wool, as this can cause corrosion.
- Always clean the aluminum or stainless steel in the direction of the metal grain to prevent marking the surface.
- Light and frequent cleanings will prolong the life and appearance of the unit.

Type of Cleaning	Instructions
Typical Cleaning	Use mild soap or detergent diluted with warm water; apply to unit with a clean sponge or cloth. Rinse with clean warm water and wipe dry. Add a small amount of vinegar to solution if a more aggressive cleaning is required.
Smears, Finger Prints, Light Dirt or Discoloration	Use an aluminum or stainless steel cleaner, depending on the unit material. Clean per the instructions on the label.
Grease, Oil or Heavy Soiling	Use a commercial detergent that does not contain chlorides, bromides or iodides. Clean per the instructions on the label.

## **Caster Cleaning & Maintenance**

Clean the product's casters regularly with mild detergent and water. A scouring pad may be used on rubber treads to remove tough debris. Periodically lubricate the product's casters with multi-temperature-rated axle grease or lubricant. The frequency of lubrication depends on moisture and humidity. See the chart below for further guidelines.

Cleaning Method	Caster Lubrication Frequency
Pressure Steamer	Once a month
Pressure Hose	Four times per year
Wiped down with soap and water	Two times per year

# **Pan Rack Assembly Instructions**


Please follow the instructions below to assemble your Direct Supply® Pan Rack.

1. Open product packaging and locate parts listed in the contents list for the particular unit:


Stainless Pan Rack			
Part	QTY	Description	
А	2	Frame	
В	6	Cross Bar	
С	4	Swivel Caster	
D	12	5/16-18 x 13/4" Hex Flange Bolt	

Aluminum Pan Rack		
Part	QTY	Description
1	2	Frame
2	2	1" Cross Bar
3	4	¾" Cross Bar
4	8	Collar
5	4	%-16 x 1¾" Hex Flange Bolt
6	8	1/4-20 x 1" Hex Bolt
7	4	Swivel Caster

2. Attach two swivel casters (7 or C) into the base of one of the frame (1 or A) pieces. Next insert the hex bolt (5 or D) through the hole at the top of the caster stem and hand thread into cross bar (2 or B). Repeat with remaining two swivel casters (7 or C) and frame (1 or A). Do not tighten bolts until step 4.



- 3. Next, attach the remaining four cross bars (3 or B). For stainless steel carts, hand thread bolt (D). For aluminum carts, first place a collar (4) over the outside of the frame and hand thread bolt (6).
- 4. Tighten all bolts with correct-sized wrench or socket; do not overtighten bolts. Adjust as needed until the cart is level.



### **Important Warnings**

To avoid serious injury and/or death, follow ALL instructions and these guidelines:

- The weight limit for this product is 350 lbs.; the weight should be evenly distributed over the unit.
  - Never load an individual shelf with more than 75 lbs.
- Overloading this product could result in the product breaking, as well as damage to property and/or serious injury.
- This product is designed for indoor use ONLY within close proximity of skilled caregivers.
- It is not designed to hold any nonfood tray or items.
- Unit should be kept away from open flames and excessive heat.
- Inspect the product for damage before each use. DO NOT use the product if it appears to be damaged or unstable, and DO NOT alter the product in any way.
- DO NOT overtighten the screws or use power tools when assembling this product.

#### **Customer Service**

Our promise to you is that you will have a convenient and easy ordering experience, receive a quality pan rack or transport cabinet and enjoy outrageous customer service. If you have any questions about the pan rack or transport cabinet you have purchased or would like to request warranty service, please contact: Direct Supply Equipment & Furnishings at 1-800-634-7328, 6767 N. Industrial Road, Milwaukee, WI 53223, SalesSupport@DirectSupply.com

### **Limited 1-Year Warranty**

Direct Supply Manufacturing, Inc. warrants to you, as the original purchaser, for the limited warranty period stated above from the date we ship the product to you that we will repair or replace any product which is defective in material or workmanship. Please note that the decision to repair or replace a product will be at our discretion.

Our warranty applies only if the product is properly maintained by the original purchaser for normal, indoor use and does not cover normal wear and tear, modification of the product, or damage caused by abuse, improper use, failure to maintain, use which exceeds the published product limitations, or the combination of any product with another product. In addition, our warranty does not cover characteristics or natural variations in wood grain, colorfastness, stains, spills or exposure to chemicals, odors, heat or light. In certain cases, we may provide you repair or adjustment instructions and/or replacement parts and ask you to perform a repair or adjustment or replace a defective part. Our warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. The limited warranty period and our obligations under the warranty end once you transfer the product to someone else or at the end of the applicable limited warranty period identified below, whichever is earlier.

DIRECT SUPPLY MANUFACTURING, INC. MAKES NO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE; THESE AND ALL OTHER IMPLIED WARRANTIES ARE SPECIFICALLY DISCLAIMED. TO THE FULLEST EXTENT ALLOWED BY LAW, DIRECT SUPPLY MANUFACTURING, INC. WILL NOT BE LIABLE FOR ANY INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, OR LOST PROFITS THAT MAY RESULT FROM THE DEVICE OR YOUR USE OF OR INABILITY TO USE THE DEVICE EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. OUR TOTAL LIABILITY TO YOU, IF ANY, IS LIMITED TO THE PRICE OF THE DEVICE OR SERVICE GIVING RISE TO YOUR CLAIM. Some states do not allow an exclusion or limitation of incidental or consequential damages, or how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. If implied warranties are not excluded, and to the extent allowed by law, we limit any and all implied warranties to the applicable warranty period identified above. Except for rights under any applicable state law, the remedies provided under this warranty are your sole and exclusive remedy for any breach of our warranty and state the entire limit of our responsibilities.



DirectSupply.com

**APTURA** 

**EQUIPMENT & FURNISHINGS** 

DSSI

TELS

Distributed by Direct Supply Manufacturing, Inc. 6635 N. Industrial Road, Milwaukee WI 53223.