











Panacea 3000/3250







Panacea 3000/3250 with Standard Assist Rails






Panacea 3000/3250 with Pivoting Assist Rails




Panacea 3000/3250 with Side Rails








Panacea 3500











Panacea 3500 with Standard Assist Rails











Panacea 3500 with Pivoting Assist Rails







Panacea 3500 with Side Rails







Pan3500 with Head and Foot Boards



Pan3250 with Head and Foot Boards