



J-Fill® Duo™/MC

Dispensing System

Accurately dispenses two J-Fill® products into spray bottles or buckets / auto scrubbers with the push of a button.

Features & Benefits

- Dispenses two products at the push of a button
- J-Fill® dispensing system will dispense accurate cleaning solutions with no measuring, mixing or mess. Metering tip in each J-Fill® cartridge ensures precise dilution and eliminates possibility of tampering with dilution ratios
- Easy product change-out
- High flow bucket fill and low flow bottle fill with Air Gap Backflow prevention
- Rugged powder coated steel construction and lockable cabinet with keys
- Uses J-Fill® Spill-Tite™/MC cartridges that are leak proof and virtually eliminates chemical exposure, tampering and manually diluting products

Applications

- For use as a dispenser in Healthcare, Food Service, Education, Retail, BSC, Government and Lodging
- Fill buckets, auto scrubbers or bottles from a central location accurately and efficiently





Use Overview

J-Fill® Duo™/MC Dispensing System safely and accurately dispenses two J-Fill products into spray bottles or buckets / auto scrubbers with the push of a button. Durable, corrosion resistant, and a lockable powder-coated steel cabinet helps prevent tampering and pilferage. Choose from two products with just the press of a button. The J-Fill Duo is factory set with one high flow and one low flow, but has the ability to be changed to both high flow or both low flow. Select a dynamic Duo of products and clean with ease.



High flow
bucket filling



Easy product
change-out



Low flow
bottle fill

Technical data	J-Fill® Duo™/MC
Depth	6.5" (16.5 cm)
Height	19.5" (49.5 cm)
Width	10" (25.4 cm)
Weight	25 lbs/11.4 kg
High Flow Rate	4.0 gal./min. (15.0 L/min.)
Low Flow Rate	1.5 gal./min. (5.1 L/min.)
Operating Range Requirements	Water Pressure: 30–85 psi (206–586 KPA) Water Flow: 2.0 gal./min. (7.6 L/min.) Water Temperature: 40–120° F (5–48° C)

ASSE 1055-B backflow prevention requirements.

Product	Description	Product code
J-Fill® Duo™/MC	J-Fill® Dispensing System	D04379



Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.