

Kensington Non-Powered Lift Occasional Chair

Kensington Non-Powered Lift Occasional Chair Dimensions:

| | |
|------------------|----------|
| Overall Height: | 41 ¼" |
| Overall Depth: | 29 ½" |
| Overall Width: | 27" |
| Seat Height: | 19 ½" |
| Seat Depth: | 20" |
| Seat Width: | 22 ½" |
| Arm Height: | 26 ½" |
| Chair Weight: | 65 lbs. |
| Weight Capacity: | 350 lbs. |
| COM Details*: | 3 ½ yds. |

Stacking:

The Kensington Non-Powered Lift Occasional Chair is nonstacking.

Cushion Details:

Seat: 2 ¼" front tapering to 1", 1850FR foam
Back: 1 ½", 1030FR foam, 2 ¼" lumbar support

Construction:

Mortise-and-tenon joints. Glued with high-solids wood glue and reinforced with 18-gauge nails, corner blocks and low-root woodscrews. Seat decks have a sinuous spring support.

Finish Details:

A wide range of standard finishes is available, and custom finishes are available upon request for an upcharge. All wood dining chairs are finished using a 9-step process that enables the chair to perform very well in a commercial environment.

| | | | | | |
|-------------|------------------|------------|-----------------|--------------|-------------------|
| aspenwood | figured mahogany | mocha | heritage walnut | corduroy | versailles anigre |
| ashbury | candlelight | cranberry | hazelnut | verona | chestnut |
| terra cotta | wild cherry | summer oak | teak | fusion maple | |

* Fabric requirement for one chair includes the seat and backrest
* COM (Customer's Own Material) is not recommended because of the fees associated with international customs.
* The estimated fabric requirement is based on 54"W (137 cm) material. The actual amount required may vary depending on pattern, pattern matching, material width or use of multiple fabrics
* The fabric on the backrest is visible from the rear view of the chair
* Different fabrics on seat and backrest is possible



Wood Details:

Species: 100% solid European beech hardwood.

Mobility Options:

The Kensington Non-Powered Lift Occasional Chair is not available with casters or inline wheels.

Functionality:

The Kensington Non-Powered Lift Occasional Chair offers the resident a gentle lift from the seated position. To operate the lift mechanism, pull the knob located on the seated resident's left side outward, and then slowly lean forward and egress from the chair. After the resident is seated, push the knob inward to lock the seat in place.

The amount of lift also can be adjusted for different sized residents. Please see the manual for adjustment instructions.

100 - 150 lbs. 150 - 250 lbs. 250 - 350 lbs.

NOTE: The Kensington Non-Powered Lift Occasional Chair will be set on the yellow setting (150 - 250 lbs.) from the factory.

Floor Glides:

All chairs ship standard with white nylon floor glides. Optional floor glides include small and large metal, large white nylon, and felt.

Regulations:

All chairs are CA117-2013 and TSCA Title VI certified. Chairs pass BIFMA X5.5 Seating Standards. CA133 option is available.

Warranty Information:

10-year limited warranty on the chair frame.
1-year limited warranty on the seat and backrest foam.
Fabric manufacturer's warranty on fabric.

Also Available in Kensington:



Kensington Occasional Chair Kensington Stationary Rocker Kensington Dining Chair Kensington Bariatric Dining Chair Kensington Counter-Height Stool Kensington Barstool