

Pressure Pad for Direct Supply® Attendant® Resident Monitors

h۱


Direct Supply Manufacturing, Inc 6699 N. Industrial Rd. Milwaukee, WI 53223

WARRANTY


45-day	1-year
	Χ

09|10|11|12|1|2|3|4|5|6|7|8|9|10|11|12

Bottom View



Use: AC Adapter
Plug pad into monitor pad jack



- The "In Use" light will blink as a visual indication that the alarm is in use
- When using pads with foam or gel cushions test system thoroughly, the weight of some cushions can reduce the effectiveness of the alarm
- To store pad, unplug from monitor
- ALWAYS TEST THE SYSTEM BEFORE EVERY USE

Maintenance:

- When battery has expired the monitor will "chirp" and "Low Battery" light will illuminate change battery immediately
- To clean pad, use disinfectant wipes or antibacterial cleaners do not fold or immerse pad in any solution
- ALWAYS TEST THE SYSTEM BEFORE EVERY USE

Start Date End Date

Use start date to track pad use.

Troubleshooting:

If your system does not function when tested follow these steps:

- Verify you are using a fully charged battery; if using the optional AC adapter, verify it is properly plugged in to both the unit and the wall
- 2. Check that the pad is plugged securely into the monitor
- 3. Some monitors have an on/off switch (Attendant Economy Monitor), if applicable make sure that the switch is in the on position
- 4. Determine which piece of equipment is at fault by either:
- a. Take a known working monitor and connect the potentially faulty pad to this monitor if the system works properly, the problem is with the original monitor
- b.Take a known working pad and connect the potentially faulty monitor to this pad - if the system works properly, the problem is with the original pad

If you determine either the pad or the monitor is not working properly, note the serial number and contact Direct Supply Equipment & Furnishings at 1-800-634-7328

573 mm 22.559 in

Artwork for 1 Year mat

Date: 01-26-2010